



---

## Fujitsu Storage ETERNUS Multipath Driver V2 (for Linux) Installation Information

---

Oct 2023

## Contents

Correspondence of ETERNUS Multipath Driver 's Version Level and Patch .....	4
Multipath Driver's Version Level and Patch correspondence table.....	4
 Supported Operating System (OS) Versions .....	5
Multipath Driver for Red Hat Enterprise Linux 6.....	5
Multipath Driver for Red Hat Enterprise Linux 7.....	5
Multipath Driver for Red Hat Enterprise Linux 8.....	6
Multipath Driver for Red Hat Enterprise Linux 9.....	6
 Restrictions and Resolution schedule.....	7
Common Restrictions for all OS .....	7
Red Hat Enterprise Linux 6.....	7
Red Hat Enterprise Linux 7.....	7
Red Hat Enterprise Linux 8.....	7
Red Hat Enterprise Linux 9.....	8
 Supported Storage Systems.....	9
ETERNUS DX60 S2, ETERNUS DX80 S2, ETERNUS DX90 S2 .....	9
ETERNUS DX60 S3, ETERNUS DX100 S3, ETERNUS DX200 S3,.....	9
ETERNUS AF150 S3, ETERNUS AF250 S3, ETERNUS AF250 S2, ETERNUS AF250 .....	9
ETERNUS DX60 S5, ETERNUS DX100 S5, ETERNUS DX200 S5 .....	10
ETERNUS DX60 S4, ETERNUS DX100 S4, ETERNUS DX200 S4 .....	10
ETERNUS DX400 S2 series.....	10
ETERNUS DX500 S5, ETERNUS DX600 S5, ETERNUS AF650 S3 .....	10
ETERNUS DX500 S4, ETERNUS DX600 S4, ETERNUS AF650 S2 .....	10
ETERNUS DX500 S3, ETERNUS DX600 S3, ETERNUS AF650 .....	10
ETERNUS DX900 S5 .....	10
ETERNUS DX8000 S2 series.....	10
ETERNUS DX8700 S3, ETERNUS DX8900 S3 .....	10
ETERNUS DX8900 S4 .....	10
 Connection Requirements .....	11
Hardware Requirements .....	11
Software Requirements .....	14
Virtualization Environments .....	14
UEFI Secure Boot .....	14
 Adapter Port Number and Connection Points .....	15
ETERNUS DX60 S2 rear view (FC, iSCSI connection) .....	16
ETERNUS DX60 S2 rear view (SAS connection) .....	16
ETERNUS DX60 S5, ETERNUS DX60 S4, ETERNUS DX60 S3 rear view .....	16
ETERNUS DX100 S5, ETERNUS DX100 S4, ETERNUS DX100 S3 rear view .....	16
ETERNUS DX200 S4, ETERNUS DX200 S3, ETERNUS AF150 S3, ETERNUS AF250 S2, ETERNUS AF250, ETERNUS DX80 S2, ETERNUS DX90 S2 rear view .....	17
ETERNUS DX200 S5, ETERNUS AF250 S3 rear view .....	17
ETERNUS DX500 S5, ETERNUS DX500 S4, ETERNUS DX500 S3, ETERNUS DX600 S5, ETERNUS DX600 S4, ETERNUS DX600 S3, ETERNUS AF650 S3, ETERNUS AF650 S2, ETERNUS AF650, ETERNUS DX400 S2 series rear view .....	17
ETERNUS DX900 S5 rear view .....	18
ETERNUS DX8100 rear view .....	18
ETERNUS DX8400, ETERNUS DX8700 front view .....	19
ETERNUS DX8100 S2 rear view .....	19
ETERNUS DX8700 S2 front view.....	20

---

ETERNUS DX8900 S4, ETERNUS DX8700 S3, ETERNUS DX8900 S3 rear view.....	21
Assigned-/Non-assigned CM Type Storage Systems .....	24
Change Unit of Storage Systems .....	25
Linux Kernel and Multipath Driver Update .....	26
Multipath Driver Update .....	26
How to Update Linux Kernel.....	26
Notes .....	27
When using Retpoline Kernel .....	27
Storage Cluster of ETERNUS DX series.....	28
FC Switch.....	28
Emulex OneCommand Manager.....	29
iSCSI .....	29
Notes when Multipath is Composed .....	29
LU Configuration .....	29
Storage/LU/Path Addition without Server Rebooting .....	29
Multiple LUN Mappings Configuration .....	29
Notes in Linux KVM environment .....	30
udev Configuration.....	30

**Trademarks**

Linux is a registered trademark of Linus Torvalds.

Red Hat is a registered trademark of Red Hat, Inc. in the U.S. and other countries.

SUSE is a registered trademark of Novell, Inc. in the United States and other countries.

SteelEye, SteelEye Technology, and LifeKeeper are registered trademarks of SteelEye Technology, Inc

The name of systems and products mentioned in this documentation is not necessarily marked with ® or TM. The other names of industrial products and companies are trademarks or registered marks.

## Correspondence of ETERNUS Multipath Driver 's Version Level and Patch

It is possible to update a version Level of ETERNUS Multipath Driver (hereafter referred to as "Multipath Driver") to a later one by applying a patch.

Example: When applying the patch T00812-39 to V2.0L27, the function is equal to V2.0L31.

The correspondence of version levels and patches is as follows.

### Multipath Driver's Version Level and Patch correspondence table

Version Level	Red Hat Enterprise Linux 6	Red Hat Enterprise Linux 7	Red Hat Enterprise Linux 8	Red Hat Enterprise Linux 9
V2.0L01	none	none	none	none
V2.0L02	none	none	none	none
V2.0L03	none	none	none	none
V2.0L10	none	none	none	none
V2.0L11	none	none	none	none
V2.0L12	none	none	none	none
V2.0L13	none	none	none	none
V2.0L14	none	none	none	none
V2.0L20	none	none	none	none
V2.0L21	none	none	none	none
V2.0L22	T00812-23	none	none	none
V2.0L23	none	none	none	none
V2.0L24	T00812-27	none	none	none
V2.0L25	T00812-28	none	none	none
V2.0L26	T00812-29	none	none	none
V2.0L27	T00812-30	T00812-30	none	none
V2.0L28	T00812-32	T00812-32	none	none
V2.0L29	T00812-34	T00812-34	none	none
V2.0L30	T00812-35*1	T00812-35	none	none
V2.0L31	ditto	T00812-39	T00812-39	none
the latest patch	T00812-35	T00812-39	T00812-39	T00812-40

\*1 The final version. The module of products/patch that is newer than the final version is the same as it.

## Supported Operating System (OS) Versions

The following tables show the version of Linux kernels supported by the Multipath Driver.

If you are going to install Multipath Driver newly, please install Multipath Driver product, don't reboot the system, and then apply the latest Multipath Driver patch. After that, please reboot the system.

### Multipath Driver for Red Hat Enterprise Linux 6

Operating System *1	Linux Kernel Versions *2	Version Level
Red Hat Enterprise Linux 6	2.6.32-71.el6	V2.0L21 or later
Red Hat Enterprise Linux 6.1	2.6.32-131.0.15.el6	
Red Hat Enterprise Linux 6.2 (for x86)	2.6.32-220.4.1.el6 *3	
Red Hat Enterprise Linux 6.2 (for Intel64)	2.6.32-220.el6	
Red Hat Enterprise Linux 6.3	2.6.32-279.el6	
Red Hat Enterprise Linux 6.4	2.6.32-358.el6	
Red Hat Enterprise Linux 6.5	2.6.32-431.el6	
Red Hat Enterprise Linux 6.6	2.6.32-504.el6	
Red Hat Enterprise Linux 6.7	2.6.32-573.el6	
Red Hat Enterprise Linux 6.8	2.6.32-642.el6	
Red Hat Enterprise Linux 6.9	2.6.32-696.el6	
Red Hat Enterprise Linux 6.10	2.6.32-754.el6	V2.0L22 or later + T00812-35 or later or V2.0L30 or later

\*1 Only x86 or Intel64 platform.

\*2 errata kernel is supported.

\*3 It is necessary to apply the Advisory ID RHSA-2012:0052-01.

### Multipath Driver for Red Hat Enterprise Linux 7

Operating System *1 *2	Linux Kernel Versions *3	Version Level
Red Hat Enterprise Linux 7	3.10.0-123.el7	V2.0L26 or later
Red Hat Enterprise Linux 7.1	3.10.0-229.el7	V2.0L27 or later
Red Hat Enterprise Linux 7.2	3.10.0-327.el7	V2.0L27 + T00812-31 or later *4 or V2.0L28 or later
Red Hat Enterprise Linux 7.3	3.10.0-514.el7	V2.0L27 + T00812-31 or later *4 or V2.0L28 or later
Red Hat Enterprise Linux 7.4	3.10.0-693.el7	V2.0L28 or later
Red Hat Enterprise Linux 7.5	3.10.0-862.el7	V2.0L29 or later
Red Hat Enterprise Linux 7.6	3.10.0-957.el7	V2.0L29 or later
Red Hat Enterprise Linux 7.7	3.10.0-1062.el7	V2.0L29 or later
Red Hat Enterprise Linux 7.8	3.10.0-1127.el7	V2.0L29 or L30 + T00812-36

Operating System *1 *2	Linux Kernel Versions *3	Version Level
		or V2.0L31 or later
Red Hat Enterprise Linux 7.9	3.10.0-1160.el7	V2.0L29 or L30 + T00812-36 or V2.0L31 or later

\*1 Only Intel64 platform.

\*2 Please refer to "[How to Update Linux Kernel](#)" without fail when you update OS.

\*3 errata kernel is supported.

\*4 Please install Multipath Driver product V2.0L27, and then apply the patch T00812-31 without fail.  
After that, please reboot the system.

## Multipath Driver for Red Hat Enterprise Linux 8

Operating System *1 *2	Linux Kernel Versions *3	Version Level
Red Hat Enterprise Linux 8.1	4.18.0-147.el8	V2.0L30 or later
Red Hat Enterprise Linux 8.2	4.18.0-193.el8	V2.0L30 + T00812-36 or later *4 or V2.0L31 or later
Red Hat Enterprise Linux 8.3	4.18.0-240.el8	V2.0L30 + T00812-37 or later *4 or V2.0L31 or later
Red Hat Enterprise Linux 8.4	4.18.0-305.el8 *5	V2.0L30 + T00812-38 *4 or V2.0L31 or later
Red Hat Enterprise Linux 8.6	4.18.0-372.9.1.el8	V2.0L30 + T00812-39 *4 or V2.0L31 or later
Red Hat Enterprise Linux 8.8	4.18.0-477.10.1.el8	V2.0L30 + T00812-39 *4 or V2.0L31 or later

\*1 Only Intel64 platform.

\*2 Please refer to "[How to Update Linux Kernel](#)" without fail when you update OS.

\*3 errata kernel is supported.

\*4 The installation of V2.0L30 fails with dependency error, but ignore the error and apply the patch.

\*5 It is necessary to apply the Advisory ID RHBA-2021:2572.

## Multipath Driver for Red Hat Enterprise Linux 9

Operating System *1 *2	Linux Kernel Versions	Version Level
Red Hat Enterprise Linux 9.0	5.14.0-70.13.1.el9 *3	V2.0L31
Red Hat Enterprise Linux 9.2	5.14.0-284.11.1.el9	V2.0L31 + T00812-40 *4

\*1 Only Intel64 platform.

\*2 Please refer to "[How to Update Linux Kernel](#)" without fail when you update OS.

\*3 RHSA-2022:8973 is not supported.

\*4 The installation of V2.0L31 fails with stat/tar error, but ignore the error and apply the patch.

## Restrictions and Resolution schedule

The Multipath Driver has following restrictions on each OS.

### Common Restrictions for all OS

Restrictions	Resolution schedule
When using iSCSI or Dual Port SAS card to connect storage systems, do not use iomadm change adapter and iomadm restart adapter commands. Use iomadm change controller and iomadm restart controller commands instead.	TBD
Cloning a system with ETERNUS Multipath Driver installed to another server is not supported.	TBD

### Red Hat Enterprise Linux 6

Restrictions	Resolution schedule
In the iSCSI boot environment, do not run the dracut command with “-hostonly” option to make an initramfs file.	TBD

### Red Hat Enterprise Linux 7

Restrictions	Resolution schedule
In the iSCSI boot environment, do not run the dracut command with “-hostonly” option to make an initramfs file.	TBD
SCSI T10 DIF/DIX function is not supported	TBD
Do not perform the following device scan on scsi_host of multipath driver. echo "c t l"> /sys/class/scsi_host/hosth/scan When you use sg3_utils package, do not use rescan-scsi-bus.sh. If the patch before T00812-32 is applied, the system may panic. If the patch T00812-33 or later is applied and rescan-scsi-bus.sh execute, all paths may be offline.	TBD
When using Red Hat Enterprise Linux 7.9, the iSCSI interface is not supported.	ETERNUS firmware V11L50-1000

### Red Hat Enterprise Linux 8

Restrictions	Resolution schedule
In the iSCSI boot environment, do not run the dracut command with “-hostonly” option to make an initramfs file.	TBD
SCSI T10 DIF/DIX function is not supported	TBD
Do not perform the following device scan on scsi_host of multipath driver. echo "c t l"> /sys/class/scsi_host/hosth/scan When you use sg3_utils package, do not use rescan-scsi-bus.sh. If rescan-scsi-bus.sh execute, all paths may be offline.	TBD
When using Red Hat Enterprise Linux 8.1, Qlogic HBA is not supported. PANIC occurs when a timeout error occurs due to an OS BUG. <a href="https://access.redhat.com/solutions/4669311">https://access.redhat.com/solutions/4669311</a>	errata (RHSA-2020:2199)

Restrictions	Resolution schedule
When using Red Hat Enterprise Linux 8.3 and 8.4, the iSCSI interface is not supported .	ETERNUS firmware V11L50-1000

## Red Hat Enterprise Linux 9

Restrictions	Resolution schedule
In the iSCSI boot environment, do not run the dracut command with “-hostonly” option to make an initramfs file.	TBD
SCSI T10 DIF/DIX function is not supported	TBD
Do not perform the following device scan on scsi_host of multipath driver. echo "c t l"> /sys/class/scsi_host/hosth/scan When you use sg3_utils package, do not use rescan-scsi-bus.sh. If rescan-scsi-bus.sh execute, all paths may be offline.	TBD
Red Hat Enterprise Linux 9.0, SAS is not supported	Red Hat Enterprise Linux 9.2
Multipath driver devices cannot be used for kdump.	TBD

## Supported Storage Systems

Multipath Driver supports the following storage systems.  
The support status needs to be confirmed from the support matrix.

ETERNUS DX60 S5/DX60 S4  
 ETERNUS DX100 S5/DX100 S4  
 ETERNUS DX200 S5/DX200 S4  
 ETERNUS DX500 S5/DX500 S4  
 ETERNUS DX600 S5/DX600 S4  
 ETERNUS DX900 S5  
 ETERNUS AF150 S3  
 ETERNUS AF250 S3, AF250 S2, AF250  
 ETERNUS AF650 S3, AF650 S2, AF650  
 ETERNUS DX60 S2  
 ETERNUS DX60 S3  
 ETERNUS DX80 S2/DX90 S2  
 ETERNUS DX100 S3/DX200 S3  
 ETERNUS DX400 S2 series  
 ETERNUS DX500 S3/DX600 S3  
 ETERNUS DX8000 S2 series  
 ETERNUS DX8700 S3/ DX8900 S3  
 ETERNUS DX8900 S4

The version of Multipath Driver which supports the storage system is as below.

### ETERNUS DX60 S2, ETERNUS DX80 S2, ETERNUS DX90 S2

Storage System	Version Level
ETERNUS DX60 S2	
ETERNUS DX80 S2	V2.0L22 or later
ETERNUS DX90 S2	

### ETERNUS DX60 S3, ETERNUS DX100 S3, ETERNUS DX200 S3, ETERNUS AF150 S3, ETERNUS AF250 S3, ETERNUS AF250 S2, ETERNUS AF250

Storage System	Version Level
ETERNUS DX60 S3	
ETERNUS DX100 S3	V2.0L25 or later
ETERNUS DX200 S3	
ETERNUS AF150 S3	
ETERNUS AF250 S3	
ETERNUS AF250 S2	V2.0L27 or later
ETERNUS AF250	

**ETERNUS DX60 S5, ETERNUS DX100 S5, ETERNUS DX200 S5  
ETERNUS DX60 S4, ETERNUS DX100 S4, ETERNUS DX200 S4**

Storage System	Version Level
ETERNUS DX60 S5	
ETERNUS DX100 S5	
ETERNUS DX200 S5	
ETERNUS DX60 S4	V2.0L26 or later
ETERNUS DX100 S4	
ETERNUS DX200 S4	

**ETERNUS DX400 S2 series**

Storage System	Version Level
ETERNUS DX400 S2 series	V2.0L22 or later

**ETERNUS DX500 S5, ETERNUS DX600 S5, ETERNUS AF650 S3  
ETERNUS DX500 S4, ETERNUS DX600 S4, ETERNUS AF650 S2  
ETERNUS DX500 S3, ETERNUS DX600 S3, ETERNUS AF650**

Storage System	Version Level
ETERNUS DX500 S5	
ETERNUS DX600 S5	
ETERNUS DX500 S4	V2.0L26 or later
ETERNUS DX600 S4	
ETERNUS DX500 S3	
ETERNUS DX600 S3	V2.0L25 or later
ETERNUS AF650 S3	
ETERNUS AF650 S2	V2.0L27 or later
ETERNUS AF650	

**ETERNUS DX900 S5**

Storage System	Version Level
ETERNUS DX900 S5	V2.0L29 or later

**ETERNUS DX8000 S2 series**

Storage System	Version Level
ETERNUS DX8000 S2 series	V2.0L22 or later

**ETERNUS DX8700 S3, ETERNUS DX8900 S3**

Storage System	Version Level
ETERNUS DX8700 S3	
ETERNUS DX8900 S3	V2.0L27 or later

**ETERNUS DX8900 S4**

Storage System	Version Level
ETERNUS DX8900 S4	V2.0L29 or later

## Connection Requirements

The tables below shows related products supported by Multipath Driver. For combination of servers and FC cards, please contact us.

## Hardware Requirements

Please use the same cards of product ID to configure a multipath access. If using the different cards of product ID, a multipath access cannot be configured. For example, the combination of a PG-FC202 and a PG-FC202 is good, but the combination of a PG-FC201 and a PG-FC202 is not good.

FC card

Server	HBAs	Version Level
PRIMERGY	PG-FC106 PG-FCD101 PG-FCD102	S26361-F2843-E1 / S26361-F2843-E201 S26361-F3023-L1 V2.0L02 or later
	PG-FC107 PG-FC201	S26361-F3141-E1 S26361-F3141-L10 S26361-F3141-L210 V2.0L03 or later
	PG-FC202(L) PG-FCD201	S26361-F3306-L1 S26361-F3306-L201 S26361-F3306-E601 / S26361-F3306-L601 V2.0L11 or later
	PY-FC201(L) PY-FC202(L) PY-FCD02 PG-FC203(L) PG-FC204(L) PG-FCD202	S26361-F3961-L1 S26361-F3961-L2 S26361-F3961-L201 S26361-F3961-L202 S26361-F3874-L1 V2.0L13 or later
	PY-FC211(L) PY-FC212(L) PG-FC205(L) PG-FC206(L)	S26361-F3631-L1 S26361-F3631-L2 V2.0L21 or later *1
	PY-FC221(L) PY-FC222(L) PY-FCD12 PYBFC221(L) PYBFC222(L) PYBFCD121 PYBFCD122	S26361-F4994-E1 S26361-F4994-E2 S26361-F4994-E402 / S26361-F4994-L402 S26361-F4994-L501 S26361-F4994-L502 V2.0L22 or later
	PY-FC311(L) PY-FC312(L)	S26361-F5313-E1 S26361-F5313-E2 S26361-F5313-E201 S26361-F5313-E202 S26361-F5313-L501 S26361-F5313-L502 V2.0L22 or later *2
	PY-FC321(L) PYBFC321(L) PY-FC322(L) PYBFC322(L)	S26361-F5580-E1 S26361-F5580-E2 S26361-F5580-E201 S26361-F5580-E202 S26361-F5580-L501 S26361-F5580-L502 V2.0L22 or later *2
	PY-FC331 PYBFC331(L) PY-FC332 PYBFC332(L)	S26361-F5596-E1 S26261-F5596-E2 S26361-F5596-E201 S26261-F5596-E202 S26361-F5596-L501 S26261-F5596-L502 V2.0L25 or later

Server	HBAs		Version Level
	PY-FC341 PYBFC341(L) PY-FC342 PYBFC342(L)	S26361-F4043-E1 S26261-F4043-E2 S26361-F4043-E201 S26261-F4043-E202 S26361-F4043-L501 S26261-F4043-L502	V2.0L25 or later
	PY-FC351 PYBFC351(L) PY-FC352 PYBFC352(L)	S26361-F4044-E1 S26261-F4044-E2 S26361-F4044-E201 S26261-F4044-E202 S26361-F4044-L501 S26261-F4044-L502	V2.0L25 or later
PRIMEQUEST 3000 series	MC-0JFCF1(L)/ MC-0JFCF2(L) MC-0JFCG1(L)/ MC-0JFCG2(L) MC-0JFCM1(L)/ MC-0JFCM2(L) MC-0JFCN1(L)/ MC-0JFCN2(L) MC-0JFCP1(L)/ MC-0JFCP2(L) MC-0JFCQ1(L)/ MC-0JFCQ2(L) MC-0JFCK1(L)/ MC-0JFCK2(L) MC-0JFCL1(L)		V2.0L26 or later
PRIMEQUEST 2000 series	MC-0JFC31 / MCX0JFC31 / MC-0JFC3L MC-0JFC41 / MCX0JFC41 / MC-0JFC4L MC-0JFC91 / MCX0JFC91 / MC-0JFC9L MC-0JFCA1 / MCX0JFCA1 / MC-0JFCAL		V2.0L22 or later
	MC-0JFC71 / MCX0JFC71 / MC-0JFC7L MC-0JFC72 / MCX0JFC72 MC-0JFC81 / MCX0JFC81 / MC-0JFC8L MC-0JFC82 / MCX0JFC82		
	MC-0JFC51 / MCX0JFC51 / MC-0JFC5L MC-0JFC61 / MCX0JFC61 / MC-0JFC6L		V2.0L26 or later *1
	MC-0JFCB1 / MCX0JFCB1 / MC-0JFCBL MC-0JFCC1 / MCX0JFCC1 / MC-0JFCCL		V2.0L26 or later *2
PRIMEQUEST 1000 series	MC-0JFC11 / MC-0JFC1L MC-0JFC21 / MC-0JFC2L		V2.0L14 or later
PRIMEQUEST 500A/500/400 series	MC-08FC11 / MC-08FC71		V2.0L01 or later
	MC-08FC31 / MC-08FC41		V2.0L03 or later
	MC-08FC51 / MC-08FC61		V2.0L13 or later
3rd party PC servers	Emulex FC cards QLogic FC cards		V2.0L02 or later
	Brocade FC cards		V2.0L20 or later

\*1 When using on Red Hat Enterprise Linux 6 (Update 1 or Update 2), please apply the patch T00812-31.

\*2 When using on Red Hat Enterprise Linux 6 (Update 4 or later), Red Hat Enterprise Linux 7,

SUSE Linux Enterprise Server 11 and SUSE Linux Enterprise Server 12, please apply the patch T00812-31.

#### SAS card

Server	HBAs		Version Level
PRIMERGY	PY-SC1Y0(L) PG-228B(L)	S26361-F3271-L1	V2.0L13 or later
	PY-SC2Z0 PG-22DC(L)	S26361-F3628-L501	
	PY-SCD08 PG-SAD201	S26361-F4480-L1	V2.0L22 or later *1
	PY-SC3FE	S26361-F3845-L501	
3rd party PC servers	LSI Logic 3Gb/s SAS cards		V2.0L13 or later
	LSI Logic 6Gb/s SAS cards		V2.0L22 or later *1

\*1 The earlier Multipath Driver doesn't support it even if applying the latest patch.

## iSCSI

Server	NICs	Version Level
PRIMERGY PRIMEQUEST 3000 series PRIMEQUEST 2000 series PRIMEQUEST 1000 series	NIC which PRIMERGY supports	V2.0L20 or later *1
3rd party PC servers	Intel Pro/1000MT etc.	

\*1 The earlier Multipath Driver doesn't support it even if applying the latest patch.

## FCoE

Server	Card	Version Level
PRIMERGY	PY-CN202(L) PG-292B(L) PG-CND201	V2.0L20 or later
	PY-CND02 PYBCND021	
	PY-CN302 PYBCN302(L) PY-CN302U PYBCN302U	
	PY-CN3A1(L) PYBCN3A1(L)	
PRIMEQUEST 3000 series	MC-0JCEL1 MC-0JCEL2	V2.0L26 or later
PRIMEQUEST 2000 series	MC-0JCE61 / MC-0JCE62	V2.0L26 or later
3rd party PC servers	Emulex CNA cards	V2.0L20 or later

**Topology**

Interface	Topology	Version Level
FC	FC-AL	V2.0L01 or later
	Fabric	
SAS	Point-to-Point	V2.0L13 or later
	Fabric *1	V2.0L22 or later
iSCSI	Point-to-Point	V2.0L20 or later
	Switch	
FCoE	Switch	V2.0L20 or later

\*1: Only ETERNUS DX80 S2, DX90 S2, DX100 S3 or DX200 S3.

**Virtualization Switch**

Model Name	Version Level
VS900 model 300	V2.0L13 or later

\* When using VS900 model 300, please set the Max Throttle to 16.

**Software Requirements****Clustering Software**

Clustering Software	Version Level
PRIMECLUSTER	V2.0L01 or later
LifeKeeper for Linux v6 or later	V2.0L12 or later

**Virtualization Environments**

Virtualization Environments	Running on Host OS	Running on Guest OS
Hyper-V	N/A	Not Supported
VMware	Not Supported	Not Supported
Linux Citrix Xen	Not Supported	Not Supported
Linux Native Xen	Not Supported	Not Supported
Linux KVM	Supported *1	Not Supported

\*1 Only Red Hat Enterprise Linux 6 and Red Hat Enterprise Linux 7, Red Hat Enterprise Linux 8.

**UEFI Secure Boot**

Server	Firmware	Version Level
PRIMERGY	N/A	Not Supported
PRIMEQUEST 3000 Series PRIMEQUEST 2000 Series	BB15071 or later	V2.0L27 or later *1
PRIMEQUEST 1000 Series	N/A	Not Supported
3rd party PC servers	N/A	Not Supported

\*1 Multipath Driver supports the UEFI Secure Boot on Red Hat Enterprise Linux 7.1 or later.  
Red Hat Enterprise Linux 8 is not supported.

## Adapter Port Number and Connection Points

The iomadm command with “info” option shows attached disks information with adapter port number as the following example. The adapter port number means a connection point and is uniquely defined on each storage system. The figures below show the adapter port number of supported storage systems.

Example:

```
# /opt/FJSVmpd/bin/iomadm info
```

IOMP: vhba0

Element:

DISK: ETERNUS\_DXM- 000001-0000-0180 (sdf)


PATH:

```
sdf 0000:02:03.0 active "online" 11, 61, 42  
sdf 0000:02:09.0 active "online" 10, 60, 40
```


Group No.      Exchange Unit No.      Adapter Port No.

Note:

An adapter port number is different from a port number. Please refer to the User’s Guide of a storage system to check a port number. The relation between the port number and the physical position of the port depends on a storage system.

**ETERNUS DX60 S2 rear view (FC, iSCSI connection)**

[ ] : Group No. ( ) : Exchange Unit No. █ : Adapter Port No. █ : When using 2 port CM

**ETERNUS DX60 S2 rear view (SAS connection)**


[ ] : Group No. ( ) : Exchange Unit No. █ : Adapter Port No. █ : When using 2 port CM

**ETERNUS DX60 S5, ETERNUS DX60 S4, ETERNUS DX60 S3 rear view**

[ ] : Group No. ( ) : Exchange Unit No. █ : Adapter Port No. █ : When using 2 port CM


**ETERNUS DX100 S5, ETERNUS DX100 S4, ETERNUS DX100 S3 rear view**

When CA of FC is installed in the basic host interface




[ ] : Group No. ( ) : Exchange unit No. █ : adapter Port No. █ : When using 2port-CA


When CA other than FC are installed in the basic host interface




[ ] : Group No. ( ) : Exchange unit No. █ : adapter Port No. █ : When using 2port-CA

**ETERNUS DX200 S4, ETERNUS DX200 S3, ETERNUS AF150 S3, ETERNUS AF250 S2, ETERNUS AF250, ETERNUS DX80 S2, ETERNUS DX90 S2 rear view**



[ ]: Group No. ( ): Exchange unit No.  : adapter Port No.  : When using 2port-CA

**ETERNUS DX200 S5, ETERNUS AF250 S3 rear view**



[ ]: Group No. ( ): Exchange unit No.  : adapter Port No.  : When using 4port-CA

**ETERNUS DX500 S5, ETERNUS DX500 S4, ETERNUS DX500 S3, ETERNUS DX600 S5, ETERNUS DX600 S4, ETERNUS DX600 S3, ETERNUS AF650 S3, ETERNUS AF650 S2, ETERNUS AF650, ETERNUS DX400 S2 series rear view**



[ ]: Group No. ( ): Exchange unit No.  : adapter Port No.  : When using 4port-CA

**ETERNUS DX900 S5 rear view**


[ ]: Group No. ( ): Exchange unit No.     : adapter Port No.     : When using 4port-CA

**ETERNUS DX8100 rear view**


[ ]: Group No. ( ): Exchange unit No.     : Adapter Port No.     : When using 4port-CA

**ETERNUS DX8400, ETERNUS DX8700 front view**

[ ] : Group No. ( ) : Exchange unit No. Orange square: Adapter Port No. Blue square: When using 4port-CA

**ETERNUS DX8100 S2 rear view**

[ ] : Group No. ( ): Exchange unit No. Orange square: adapter Port No. Green square: When using 4port-CA

**ETERNUS DX8700 S2 front view**

[ ]: Group No. ( ): Exchange unit No.      Orange Box : adapter Port No.      Green Box : When using 4port-CA

**ETERNUS DX8900 S4, ETERNUS DX8700 S3, ETERNUS DX8900 S3 rear view**

CE0		CM1 [20]				CM0 [10]					
CE1		CM1 [21]				CM0 [11]					
CE2		CM1 [22]				CM0 [12]					
PSU0	PSU1	CA2 (61)	0042	0043	0052	0053	CA3 (71)	0062	0063	0072	0073
		CA0 (41)	0002	0003	0012	0013	CA1 (51)	0022	0023	0032	0033
PSU0	PSU1	CA2 (60)	0040	0041	0050	0051	CA3 (70)	0060	0061	0070	0071
		CA0 (40)	0000	0001	0010	0011	CA1 (50)	0020	0021	0030	0031
PSU0	PSU1	CA2 (63)	0046	0047	0056	0057	CA3 (73)	0066	0067	0076	0077
		CA0 (43)	0006	0007	0016	0017	CA1 (53)	0026	0027	0036	0037
PSU0	PSU1	CA2 (62)	0044	0045	0054	0055	CA3 (72)	0064	0065	0074	0075
		CA0 (42)	0004	0005	0014	0015	CA1 (52)	0024	0025	0034	0035
PSU0	PSU1	CA2 (65)	004A	004B	005A	005B	CA3 (75)	006A	006B	007A	007B
		CA0 (45)	000A	000B	001A	001B	CA1 (55)	002A	002B	003A	003B
PSU0	PSU1	CA2 (64)	0048	0049	0058	0059	CA3 (74)	0068	0069	0078	0079
		CA0 (44)	0008	0009	0018	0019	CA1 (54)	0028	0029	0038	0039
PSU0	PSU1	CA2 (67)	004E	004F	005E	005F	CA3 (77)	006E	006F	007E	007F
		CA0 (47)	000E	000F	001E	001F	CA1 (57)	002E	002F	003E	003F
PSU0	PSU1	CA2 (66)	004C	004D	005C	005D	CA3 (76)	006C	006D	007C	007D
		CA0 (46)	000C	000D	001C	001D	CA1 (56)	002C	002D	003C	003D

[ ]: Group No. ( ): Exchange unit No.      : adapter Port No.      : When using 4port-CA

CE4		CM1	CA2 (A1) 00C2 00C3 00D2 00D3	CA3 (B1) 00E2 00E3 00F2 00F3
PSU0	PSU1	[24]	CA0 (81) 0082 0083 0092 0093	CA1 (91) 00A2 00A3 00B2 00B3
		CM0	CA2 (A0) 00C0 00C1 00D0 00D1	CA3 (B0) 00E0 00E1 00F0 00F1
PSU0	PSU1	[14]	CA0 (80) 0080 0081 0090 0091	CA1 (90) 00A0 00A1 00B0 00B1
		CM1	CA2 (A3) 00C6 00C7 00D6 00D7	CA3 (B3) 00E6 00E7 00F6 00F7
PSU0	PSU1	[25]	CA0 (83) 0086 0087 0096 0097	CA1 (93) 00A6 00A7 00B6 00B7
		CM0	CA2 (A2) 00C4 00C5 00D4 00D5	CA3 (B2) 00E4 00E5 00F4 00F5
PSU0	PSU1	[15]	CA0 (82) 0084 0085 0094 0095	CA1 (92) 00A4 00A5 00B4 00B5
		CM1	CA2 (A5) 00CA 00CB 00DA 00DB	CA3 (B5) 00EA 00EB 00FA 00FB
PSU0	PSU1	[26]	CA0 (85) 008A 008B 009A 009B	CA1 (95) 00AA 00AB 00BA 00BB
		CM0	CA2 (A4) 00C8 00C9 00D8 00D9	CA3 (B4) 00E8 00E9 00F8 00F9
PSU0	PSU1	[16]	CA0 (84) 0088 0089 0098 0099	CA1 (94) 00A8 00A9 00B8 00B9
		CM1	CA2 (A7) 00CE 00CF 00DE 00DF	CA3 (B7) 00EE 00EF 00FE 00FF
PSU0	PSU1	[27]	CA0 (87) 008E 008F 009E 009F	CA1 (97) 00AE 00AF 00BE 00BF
		CM0	CA2 (A6) 00CC 00CD 00DC 00DD	CA3 (B6) 00EC 00ED 00FC 00FD
PSU0	PSU1	[17]	CA0 (86) 008C 008D 009C 009D	CA1 (96) 00AC 00AD 00BC 00BD

[: Group No. (): Exchange unit No. : adapter Port No. : When using 4port-CA

CE8		CM1 [28]	CA2 (E1) 0142 0143 0152 0153	CA3 (F1) 0162 0163 0172 0173
PSU0	PSU1	CA0 (C1)	0102 0103 0112 0113	CA1 (D1) 0122 0123 0132 0133
		CM0 [18]	CA2 (E0) 0140 0141 0150 0151	CA3 (F0) 0160 0161 0170 0171
		CA0 (C0)	0100 0101 0110 0111	CA1 (D0) 0120 0121 0130 0131
		CM1 [29]	CA2 (E3) 0146 0147 0156 0157	CA3 (F3) 0166 0167 0176 0177
		CA0 (C3)	0106 0107 0116 0117	CA1 (D3) 0126 0127 0136 0137
		CM0 [19]	CA2 (E2) 0144 0145 0154 0155	CA3 (F2) 0164 0165 0174 0175
		CA0 (C2)	0104 0105 0114 0115	CA1 (D2) 0124 0125 0134 0135
CE9		CM1 [2A]	CA2 (E5) 014A 014B 015A 015B	CA3 (F5) 016A 016B 017A 017B
PSU0	PSU1	CA0 (C5)	010A 010B 011A 011B	CA1 (D5) 012A 012B 013A 013B
		CM0 [1A]	CA2 (E4) 0148 0149 0158 0159	CA3 (F4) 0168 0169 0178 0179
		CA0 (C4)	0108 0109 0118 0119	CA1 (D4) 0128 0129 0138 0139
CE10		CM1 [2B]	CA2 (E7) 014E 014F 015E 015F	CA3 (F7) 016E 016F 017E 017F
PSU0	PSU1	CA0 (C7)	010E 010F 011E 011F	CA1 (D7) 012E 012F 013E 013F
		CM0 [1B]	CA2 (E6) 014C 014D 015C 015D	CA3 (F6) 016C 016D 017C 017D
		CA0 (C6)	010C 010D 011C 011D	CA1 (D6) 012C 012D 013C 013D
CE11				

[ ]: Group No. ( ): Exchange unit No.      : adapter Port No.      : When using 4port-CA

## Assigned-/Non-assigned CM Type Storage Systems

For ETERNUS storage systems, there are two system types: "Assigned-CM" and "Non-assigned-CM." With Assigned-CM storage systems, the main access path for each LU is assigned to a particular controller. With Non-assigned-CM storage systems, there are no assigned LU access paths as such.

With "Assigned-CM" type storage systems, the path connected to the assigned controller is active. Paths to other controllers are on standby. With "Non-assigned-CM" type storage systems, all paths are active and used for access.

The table below shows the "Assigned-CM" and "Non-assigned-CM" storage systems.

Load balancing/Failover performance can differ depending on "Assigned-CM" and "Non-assigned-CM" use and the number of paths employed. For details, refer to the supplied product manual.

Assigned CM type	ETERNUS DX60 S5, DX60 S4, DX60 S3 ETERNUS DX100 S5, DX100 S4, DX100 S3 ETERNUS DX200 S5, DX200 S4, DX200 S3 ETERNUS DX500 S5, DX500 S4, DX500 S3 ETERNUS DX600 S5, DX600 S4, DX600 S3 ETERNUS DX60 S2, ETERNUS DX80 S2 ETERNUS DX90 S2 ETERNUS DX400 S2 series ETERNUS AF150 S3 ETERNUS AF250 S3, AF250 S2, AF250 ETERNUS AF650 S3, AF650 S2, AF650
Non-assigned CM type	ETERNUS DX900 S5 ETERNUS DX8900 S4 ETERNUS DX8000 S3 series ETERNUS DX8000 S2 seies

## Change Unit of Storage Systems

The iompadm change/restart command has a “change unit” parameter. The change unit represents a module of a storage system as follows.

Storage System	cu/controllerunit	g/groupmodule
ETERNUS DX60 S5, DX60 S4, DX60 S3 ETERNUS DX100 S5, DX100 S4, DX100 S3 ETERNUS DX200 S5, DX200 S4, DX200 S3 ETERNUS DX60 S2 ETERNUS DX80 S2 ETERNUS DX90 S2 ETERNUS AF150 S3 ETERNUS AF250 S3, AF250 S2, AF250	-	CM
ETERNUS DX500 S5, DX500 S4, DX500 S3 ETERNUS DX600 S5, DX600 S4, DX600 S3 ETERNUS DX900 S5 ETERNUS DX8700 S3/DX8900 S3 ETERNUS DX400 S2 series ETERNUS DX8000 S2 series ETERNUS DX8900 S4 ETERNUS AF650 S3, AF650 S2, AF650	CA	CM

When a CA of ETERNUS DX500 S4 is exchanged, the change unit must be cu or controllerunit. When a CM of ETERNUS DX100 S4 is exchanged, the change unit must be g or groupmodule.

## Linux Kernel and Multipath Driver Update

### Multipath Driver Update

Never use ‘-U’ option of the rpm command. Please check a software information or a patch installation manual.

### How to Update Linux Kernel

Apply the latest patch of Multipath Driver Update the Linux kernel. If the update fails, refer to the next section.

#### 1. In the case of Red Hat Enterprise Linux 7, Red Hat Enterprise Linux 8

If a kernel is updated, make sure to execute the following command before rebooting the OS.

```
# /opt/FJSVmpd/system/mpdchkdup
```

If the following message is displayed, the Multipath Driver cannot operate with the updated kernel.  
Change the configuration to a single path, or update the Multipath Driver.

!!! ERROR !!!

In ETERNUS Multipath Driver, this kernel is not supported.

## Notes

### When using Retpoline Kernel

1) About the patch for Retpoline

Please apply the following patch when you use Retpoline Kernel before V2.0L29.

T00812-35 or later

[Relpoline Kernel]

< Red Hat Enterprise Linux 7 >

Red Hat Enterprise Linux 7.2 AUS errata (RHBA-2018:0390) Kernel-3.10.0-327.64.1.el7 or later

Red Hat Enterprise Linux 7.3 EUS/AUS errata (RHSA-2018:0399) Kernel-3.10.0-514.44.1.el7 or later

Red Hat Enterprise Linux 7.4 errata (RHSA-2018:0395) Kernel-3.10.0-693.21.1.el7 or later

< Red Hat Enterprise Linux 6 >

Red Hat Enterprise Linux 6.4 AUS errata (RHBA-2018:0509) Kernel-2.6.32-358.87.1.el6 or later

Red Hat Enterprise Linux 6.5 AUS errata (RHBA-2018:0394) Kernel-2.6.32-431.87.1.el6 or later

Red Hat Enterprise Linux 6.6 AUS errata (RHBA-2018:0507) Kernel-2.6.32-504.66.1.el6 or later

Red Hat Enterprise Linux 6.7 EUS/AUS errata (RHSA-2018:0496) Kernel-2.6.32-573.53.1.el6 or later

Red Hat Enterprise Linux 6.9 errata (RHSA-2018:0512) Kernel-2.6.32-696.23.1.el6 or later

When not applying patch, the following warning message is output to the system log (/var/log/messages etc.) when the server booted.

WARNING: module 'mpdt' built without retpoline-enabled compiler, may affect Spectre v2 mitigation

2) Patch application procedure

- When using Retpoline Kernel

After the patch is applied, the Retpoline driver is installed. The warning message is not output.

- When using non-Retpoline Kernel (\*2)

After the patch is applied, the Retpoline driver is not installed. Therefore, when errata of [Retpoline Kernel] is applied after the patch is applied, the warning message is output.

Please install the driver according to the following procedures. As a result, the warning message is not output.

[Install the Retpoline driver]

1. Install the Retpoline driver.

```
# /opt/FJSVmpd/system/mpdchkpr
```

```
Preparing... ##### [100%]
```

```
1:kmod-FJSVmpd_rh ##### [100%]
```

```
:
```

Please reboot this system.

2. Reboot the server.

```
# reboot
```

\*2 Kernel that errata of [Retpoline Kernel] is not applied.

3) Notes

Please replace the driver according to the following procedures when switching from Retpoline Kernel to non-Retpoline Kernel.

1. The default boot is set to target Kernel(non-Retpoline Kernel) by using boot loader.

2. Install the non-Retpoline driver.

```
# /opt/FJSVmpd/system/mpdchkpr chgpk
```

```
Preparing... ##### [100%]
```

```
1:kmod-FJSVmpd_rh ##### [100%]
```

- :
- Please reboot this system.
3. Reboot the server.  
# reboot

**[Note]**

When you change Kernel from non-Retpoline Kernel to Retpoline kernel again,  
Please execute the procedure described in "2) [Install the Retpoline driver]".

## **Storage Cluster of ETERNUS DX series**

Please set it according to the following procedures when ETERNUS DX series is connected with the server by the iSCSI interface, and the Storage Cluster function is used.

1. Please edit the mpd.conf file of /var/opt/FJSVmpd/ directory.  
Please add "mpdh-nocon-retry=120" to the part of "# Global define".

Example:

```
# Global define
mpdh-set-order=0;
mpdh-rsv-key=5004c9cb;
dev_loss_tmo=2147483;
fast_io_fail_tmo=1;
mpdh-nocon-retry=120;
```

2. Please execute the following commands.

```
# /opt/FJSVmpd/bin/mpdconfig -g
```

Procedure for releasing setting

1. Please edit the mpd.conf file of /var/opt/FJSVmpd/ directory.  
Please delete "mpdh-nocon-retry=120" added to "# Global define".

2. Please execute the following commands.

```
# /opt/FJSVmpd/bin/mpdconfig -g
```

When the Storage failover/fallback of Storage Cluster is done while recognizing the multipath of the server start etc. , the multipath might not be recognized.

In this case, please recognize the multipath again by the following commands.

```
# /opt/FJSVmpd/bin/mpdconfig -a
```

## **FC Switch**

When using Multipath Driver with FC switches, zoning settings must be defined. For the details of setting zones, please refer to the manual of FC switches.

When connecting to both the storage system that is supported by Multipath Driver and the storage system that is not supported by Multipath Driver, use different HBA(or port) in both storage systems.

## Emulex OneCommand Manager

When using Emulex OneCommand Manager on Red Hat Enterprise Linux 7.1, please run the following command to load sg driver.

```
# modprobe sg
```

## iSCSI

When iSCSI interface is used to connect storage systems, please set the iSCSI timer using the iscsadm command. Please refer to the guide of the storage system for details concerning the use of iSCSI initiator.

When executing the "iopadm info" command, the pci\_bus\_number of iSCSI path displayed "platform".

## Notes when Multipath is Composed

Please connect the HBA in the server and the disk array device as there is a redundancy.

For instance, please use CM0 and CM1 of ETEURNUS DX400 series to configure multipaths.

Moreover, it is necessary to consider even number/odd number of CM for the disk array device with three CMs or more such as ETEURNUS DX8000 series.

Contact a Fujitsu engineer for details.

## LU Configuration

The LU number has to be allocated from 0 in ascending order, and the LU configuration of each port that configure a multipath has to be equal. Please refer to the manual of ETERNUS storage system for the details of how to set LUN Mapping, Affinity Group or Zone and how to check a logical volume number.


## Storage/LU/Path Addition without Server Rebooting

When executing the "iopadm info" command just behind the addition, the path\_status may be displayed as follows.  
fail "empty status"

In that case, please execute the "iopadm info" command after it waits for a moment.

## Multiple LUN Mappings Configuration

In the case of Multipath Driver V2.0L10 or later, a server can recognize multiple LUN Mappings, Affinity Group or Zones set in a storage system as follows.



### LUN Mapping 1

The logical volume (LUN\_V) #0 is mapped on LU#0, and the logical volume (LUN\_V) #1 is mapped on LU#1.

### LUN Mapping 2

The logical volume (LUN\_V) #2 is mapped on LU#0, and the logical volume (LUN\_V) #3 is mapped on LU#1.

## Notes in Linux KVM environment

It is necessary to do the following procedures in guest OS.

- Guest OS is Red Hat Enterprise Linux 6, and
- LU of the storage system is allocated on a virtual disk as IDE Disk for guest OS.

1. Please arrange "50- ide.rules" in /etc/udev/rules.d/directory.

Please set the following to "50- ide.rules".

```
ACTION=="add", SUBSYSTEM=="scsi" , SYSFS{type}=="0", RUN+="/bin/sh -c 'echo 40 > /sys$DEVPATH/timeout'"
```

2. Please reboot guest OS.

## udev Configuration

Please use by-id names of udev function.

When the Multipath Driver is installed, the by-path names as the device names of the disks in the storage system cannot be used. To install the Multipath Driver into the system where the by-path names are used as the device names of the disks in the storage system, change the by-path names in all setting files to the by-id names.

### 1. Correspondence between the by-id names and the usual /dev/sda type names

The by-id names are symbolic link to /dev/sdX name. So you can confirm relation between the by-id name and /dev/sdX name by executing the 'ls -l /dev/disk/by-id' command.

Example: Check the by-id name of /dev/sdb

```
# ls -l /dev/disk/by-id/
total 0
lrwxrwxrwx 1 root root 9 Dec  2 2006 scsi-3600e000000cb0000000000001000000000 -> ../../sdb
lrwxrwxrwx 1 root root 9 Dec  2 2006 scsi-3600e000000cb000000000000100010000 -> ../../sdc
```

The result shows that the by-id name of /dev/sdb is /dev/disk/by-id/scsi-3600e000000cb000000000000100000000.

### 2. Notice

When you use by-id names as device names of disks in a storage system, change all storage system related settings of OS and applications from /dev/sdX type names to by-id names.

It isn't necessary to use the recognition order setting (fixed-recognition-order initial RAM disk), if by-id names are specified as the device names for all configuration file such as /etc/fstab.

## Installer rescue mode

The ETERNUS multipath driver does not work when booted in installer rescue mode. As a result, the LUN may be visible for several paths or the partition may not be visible.

Therefore, if you want to access ETERNUS LUNs in installer resume mode, configure them in a single-path configuration and boot them in installer resume mode.

#### About This Installation Information

This Installation Information is devoted to providing technical information and an overview of the basic facilities of Multipath Driver. The contents of this document may be modified without any prior notice.  
Please contact FUJITSU LIMITED if you find any error in descriptions.

FUJITSU LIMITED is not responsible for indemnity that might be caused by the contents in this documentation or any damage related to contents in this documentation.

---

FUJITSU LIMITED  
<https://www.fujitsu.com/global/products/computing/storage/>